

OsmoGbProxy VTY Reference

Copyright © 2019

This work is copyright by sysmocom - s.f.m.c. GmbH. All rights reserved.

COLLABORATORS

	<i>TITLE :</i> OsmoGbProxy VTY Reference		
<i>ACTION</i>	<i>NAME</i>	<i>DATE</i>	<i>SIGNATURE</i>
WRITTEN BY		May 26, 2020	

REVISION HISTORY

NUMBER	DATE	DESCRIPTION	NAME
v1	2nd December 2019	Initial	hw

Contents

1	VTY reference	1
1.1	Common Commands	1
1.1.1	end	2
1.1.2	exit	2
1.1.3	help	2
1.1.4	list	2
1.1.5	show running-config	3
1.1.6	write	3
1.1.7	write file [PATH]	3
1.1.8	write memory	3
1.1.9	write terminal	4
1.2	view	4
1.2.1	enable	4
1.2.2	logging color (0 1)	4
1.2.3	logging disable	5
1.2.4	logging enable	5
1.2.5	logging filter all (0 1)	5
1.2.6	logging filter nsvc (nsei nsvci) <0-65535>	6
1.2.7	logging level (lgpr nslbssgpl global lapd linpl mux lmillmib lsm lctrl lgtpl ...	6
1.2.8	logging level force-all (debug info notice error fatal)	8
1.2.9	logging level set-all (debug info notice error fatal)	8
1.2.10	logging print category (0 1)	9
1.2.11	logging print category-hex (0 1)	10
1.2.12	logging print extended-timestamp (0 1)	10
1.2.13	logging print file (0 1 basename) [last]	11
1.2.14	logging print level (0 1)	11
1.2.15	logging set-log-mask MASK	12
1.2.16	logging timestamp (0 1)	12
1.2.17	logp (lgpr nslbssgpl global lapd linpl mux lmillmib lsm lctrl lgtpl stats lgs...	12
1.2.18	no logging level force-all	14

1.2.19	show alarms	15
1.2.20	show asciidoc counters	15
1.2.21	show gbproxy [stats]	15
1.2.22	show gbproxy links	16
1.2.23	show history	16
1.2.24	show logging vty	16
1.2.25	show ns	17
1.2.26	show ns (nseilnsvc) <0-65535> [stats]	17
1.2.27	show ns persistent	17
1.2.28	show ns stats	18
1.2.29	show online-help	18
1.2.30	show rate-counters	18
1.2.31	show stats	19
1.2.32	show stats level (globalpeer subscriber)	19
1.2.33	show talloc-context (application all) (full brief DEPTH)	19
1.2.34	show talloc-context (application all) (full brief DEPTH) filter REGEXP	20
1.2.35	show talloc-context (application all) (full brief DEPTH) tree ADDRESS	21
1.2.36	show version	21
1.2.37	terminal length <0-512>	22
1.2.38	terminal no length	22
1.2.39	who	22
1.3	enable	22
1.3.1	configure terminal	23
1.3.2	copy running-config startup-config	23
1.3.3	delete-gbproxy-link <0-65534> (stale de-registered)	23
1.3.4	delete-gbproxy-link <0-65534> (tlilimsilsgsn-nsei) IDENT	24
1.3.5	delete-gbproxy-peer <0-65534> (only-bvclonly-nsvcl all) [dry-run]	24
1.3.6	delete-gbproxy-peer <0-65534> bvci <2-65534>	25
1.3.7	disable	25
1.3.8	logging color (0 1)	25
1.3.9	logging disable	26
1.3.10	logging enable	26
1.3.11	logging filter all (0 1)	26
1.3.12	logging filter nsvc (nseilnsvci) <0-65535>	27
1.3.13	logging level (lgpr nslbssgpl global llapdllinpllmuxllmillmibllsmsllctrl lgtpl...	27
1.3.14	logging level force-all (debug info notice error fatal)	29
1.3.15	logging level set-all (debug info notice error fatal)	29
1.3.16	logging print category (0 1)	30
1.3.17	logging print category-hex (0 1)	31

1.3.18	logging print extended-timestamp (0 1)	31
1.3.19	logging print file (0 1 basename) [last]	32
1.3.20	logging print level (0 1)	32
1.3.21	logging set-log-mask MASK	33
1.3.22	logging timestamp (0 1)	33
1.3.23	logp (lgpr nsl bssgpl global lapd linp lmux lmil mibl sms lctrl lgtpl stats lgs...	33
1.3.24	no logging level force-all	35
1.3.25	nsvc (nseilnsvci) <0-65535> (block unblock reset)	36
1.3.26	show alarms	36
1.3.27	show asciidoc counters	36
1.3.28	show gbproxy [stats]	37
1.3.29	show gbproxy links	37
1.3.30	show history	37
1.3.31	show logging vty	38
1.3.32	show ns	38
1.3.33	show ns (nseilnsvc) <0-65535> [stats]	38
1.3.34	show ns persistent	39
1.3.35	show ns stats	39
1.3.36	show online-help	39
1.3.37	show rate-counters	40
1.3.38	show startup-config	40
1.3.39	show stats	40
1.3.40	show stats level (global peer subscriber)	41
1.3.41	show talloc-context (application all) (full brief DEPTH)	41
1.3.42	show talloc-context (application all) (full brief DEPTH) filter REGEXP	42
1.3.43	show talloc-context (application all) (full brief DEPTH) tree ADDRESS	42
1.3.44	show version	43
1.3.45	terminal length <0-512>	43
1.3.46	terminal monitor	44
1.3.47	terminal no length	44
1.3.48	terminal no monitor	44
1.3.49	who	45
1.4	config	45
1.4.1	banner motd default	45
1.4.2	banner motd file [FILE]	45
1.4.3	enable password (8) WORD	46
1.4.4	enable password LINE	46
1.4.5	gbproxy	46
1.4.6	hostname WORD	47

1.4.7	line vty	47
1.4.8	log alarms <2-32700>	47
1.4.9	log file .FILENAME	48
1.4.10	log gsmtap [HOSTNAME]	48
1.4.11	log stderr	48
1.4.12	log syslog (authpriv cron daemon ftp lpr mail news user uucp)	49
1.4.13	log syslog local <0-7>	49
1.4.14	no banner motd	50
1.4.15	no enable password	50
1.4.16	no hostname [HOSTNAME]	50
1.4.17	no log alarms	51
1.4.18	no log file .FILENAME	51
1.4.19	no log stderr	51
1.4.20	no log syslog	52
1.4.21	no service advanced-vty	52
1.4.22	no service terminal-length [<0-512>]	52
1.4.23	no stats reporter log	53
1.4.24	no stats reporter statsd	53
1.4.25	ns	53
1.4.26	password (8l) WORD	54
1.4.27	password LINE	54
1.4.28	service advanced-vty	54
1.4.29	service terminal-length <0-512>	55
1.4.30	show history	55
1.4.31	stats interval <1-65535>	55
1.4.32	stats reporter log	56
1.4.33	stats reporter statsd	56
1.5	config-log	56
1.5.1	logging color (0l1)	56
1.5.2	logging filter all (0l1)	57
1.5.3	logging filter nsvc (nsei nsvci) <0-65535>	57
1.5.4	logging level (lgpr nslbssgpl global llapdllinpllmuxllmillmibllsmsllctrlllgtpl...	58
1.5.5	logging level force-all (debug info notice error fatal)	60
1.5.6	logging level set-all (debug info notice error fatal)	60
1.5.7	logging print category (0l1)	61
1.5.8	logging print category-hex (0l1)	61
1.5.9	logging print extended-timestamp (0l1)	62
1.5.10	logging print file (0l1 basename) [last]	62
1.5.11	logging print level (0l1)	63

1.5.12	logging timestamp (0 1)	63
1.5.13	no logging level force-all	63
1.6	config-stats	64
1.6.1	disable	64
1.6.2	enable	64
1.6.3	level (globalpeerlsubscriber)	64
1.6.4	local-ip ADDR	65
1.6.5	mtu <100-65535>	65
1.6.6	no local-ip	65
1.6.7	no mtu	65
1.6.8	no prefix	66
1.6.9	prefix PREFIX	66
1.6.10	remote-ip ADDR	66
1.6.11	remote-port <1-65535>	66
1.7	config-line	67
1.7.1	bind A.B.C.D [<0-65535>]	67
1.7.2	login	67
1.7.3	no login	67
1.8	config-ns	68
1.8.1	encapsulation framerelay-gre enabled (1 0)	68
1.8.2	encapsulation framerelay-gre local-ip A.B.C.D	68
1.8.3	encapsulation udp dscp <0-255>	69
1.8.4	encapsulation udp local-ip A.B.C.D	69
1.8.5	encapsulation udp local-port <0-65535>	69
1.8.6	no nse <0-65535>	70
1.8.7	nse <0-65535> encapsulation (udplframerelay-gre)	70
1.8.8	nse <0-65535> fr-dlci <16-1007>	71
1.8.9	nse <0-65535> nsvci <0-65534>	71
1.8.10	nse <0-65535> remote-ip A.B.C.D	71
1.8.11	nse <0-65535> remote-port <0-65535>	72
1.8.12	nse <0-65535> remote-role (sgsnlbss)	72
1.8.13	timer (tns-block tns-block-retries tns-reset tns-reset-retries tns-test tns-aliv...	73
1.9	config-gbproxy	73
1.9.1	acquire-imsi	73
1.9.2	core-access-point-name (APN none)	74
1.9.3	core-mobile-country-code <1-999>	74
1.9.4	core-mobile-network-code <1-999>	74
1.9.5	link stored-msgs-max-length <1-99999>	75
1.9.6	link-list clean-stale-timer <1-999999>	75

1.9.7	link-list keep-mode (never re-attach identified always)	75
1.9.8	link-list max-age <1-999999>	76
1.9.9	link-list max-length <1-99999>	76
1.9.10	match-imsi (patching routing) .REGEXP	77
1.9.11	no acquire-imsi	77
1.9.12	no core-access-point-name	77
1.9.13	no core-mobile-country-code	78
1.9.14	no core-mobile-network-code	78
1.9.15	no link stored-msgs-max-length	78
1.9.16	no link-list clean-stale-timer	79
1.9.17	no link-list max-age	79
1.9.18	no link-list max-length	79
1.9.19	no match-imsi	80
1.9.20	no patch-ptmsi	80
1.9.21	no secondary-sgsn	80
1.9.22	patch-ptmsi	80
1.9.23	secondary-sgsn nsei <0-65534>	81
1.9.24	sgsn nsei <0-65534>	81

List of Tables

1.1	VTY Parameter Patterns	1
1.2	VTY port numbers	1

Chapter 1

VTY reference

The Virtual Tele Type (VTY) has the concept of nodes and commands. This chapter lists all nodes and the commands that are available within the node. Each command can consist out of several words followed by a variable number of parameters. There are common patterns for the parameters, these include IPv4 addresses, number ranges, a word, a line of text and choice. The following will explain the commonly used patterns.

Pattern	Example	Explanation
A.B.C.D	127.0.0.1	A IPv4 address
TEXT	example01	A single string without any spaces, tabs
.TEXT	Some information	A line of text
(OptionA OptionB OptionC)	OptionA	A choice between a list of available options
<0-10>	5	A number from a range

Table 1.1: VTY Parameter Patterns

The application is configured through the VTY. For configuring a system one needs to enter the **enable** node and then enter the **configure terminal** command. Then the configuration can be made according to the available commands. After the system has been configured one can use the **write** command to write the new configuration to the configuration file. The new file will be used after the application has been restarted.

The following table lists the TCP port numbers of the VTY for the various Osmocom GSM related programs as used on sysmocom products:

Port Number	Software
4240	osmo-pcu
4241	osmo-bts
4242	osmo-nitb, osmo-bsc
4243	osmo-bsc_mgcp
4244	osmo-bsc_nat
4245	osmo-sgsn
4246	osmo-gbproxy

Table 1.2: VTY port numbers

Common Commands

These commands are available on all VTY nodes. They are listed here only once, to unclutter the VTY reference.

end

Command

```
end
```

Parameters

end

End current mode and change to enable mode.

exit

Command

```
exit
```

Parameters

exit

Exit current mode and down to previous mode

help

Command

```
help
```

Parameters

help

Description of the interactive help system

list

Command

```
list
```

Parameters

list

Print command list

show running-config

Command

```
show running-config
```

Parameters

show

Show running system information

running-config

running configuration

write

Command

```
write
```

Parameters

write

Write running configuration to memory, network, or terminal

write file [PATH]

Command

```
write file [PATH]
```

Parameters

write

Write running configuration to memory, network, or terminal

file

Write to configuration file

[PATH]

Set file path to store the config, or replace if already exists

write memory

Command

```
write memory
```

Parameters

write

Write running configuration to memory, network, or terminal

memory

Write configuration to the file (same as write file)

write terminal

Command

```
write terminal
```

Parameters

write

Write running configuration to memory, network, or terminal

terminal

Write to terminal

view

The view node is the default node when connecting to the VTY interface. This node does not require any additional permission and allows to introspect the application.

enable

Command

```
enable
```

Parameters

enable

Turn on privileged mode command

logging color (0|1)

Command

```
logging color (0|1)
```

Parameters

logging

Configure logging

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

logging disable

Command

```
logging disable
```

Parameters

logging

Configure logging

disable

Disables logging to this vty

logging enable

This command is required to make logging commands available on the telnet VTY.

Command

```
logging enable
```

Parameters

logging

Configure logging

enable

Enables logging to this vty

logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

Command

```
logging filter all (0|1)
```

Parameters

logging

Configure logging

filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

logging filter nsvc (nsei|nsvci) <0-65535>

Command

```
logging filter nsvc (nsei|nsvci) <0-65535>
```

Parameters

logging

Configure logging

filter

Filter log messages

nsvc

Filter based on NS Virtual Connection

nsei

Identify NS-VC by NSEI

nsvci

Identify NS-VC by NSVCI

<0-65535>

Numeric identifier

logging level (|gprs|ns|bssgp|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|l...

Command

```
logging level (|gprs|ns|bssgp|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats| ↵  
lgsup|loap|lss7|lsccp|lsua|lm3ua|lmgcp|ljibuf|lrspro) (debug|info|notice|error| ↵  
fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

gprs

GPRS Packet Service

ns

GPRS Network Service (NS)

bssgp

GPRS BSS Gateway Protocol (BSSGP)

lglobal

Library-internal global log family

llapd
LAPD in libosmogsm

linp
A-bis Input Subsystem

lmux
A-bis B-Subchannel TRAU Frame Multiplex

lmi
A-bis Input Driver for Signalling

lmib
A-bis Input Driver for B-Channels (voice)

lsms
Layer3 Short Message Service (SMS)

lctrl
Control Interface

lgtp
GPRS GTP library

lstats
Statistics messages and logging

lgsup
Generic Subscriber Update Protocol

loap
Osmocom Authentication Protocol

lss7
libosmo-sigtran Signalling System 7

lsccp
libosmo-sigtran SCCP Implementation

lsua
libosmo-sigtran SCCP User Adaptation

lm3ua
libosmo-sigtran MTP3 User Adaptation

lmgcp
libosmo-mgcp Media Gateway Control Protocol

ljibuf
libosmo-netif Jitter Buffer

lrspro
Remote SIM protocol

debug
Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

logging level force-all (debug|info|notice|error|fatal)**Command**

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters**logging**

Configure logging

level

Set the log level for a specified category

force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

logging level set-all (debug|info|notice|error|fatal)**Command**

```
logging level set-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

logging print extended-timestamp (0|1)

Command

```
logging print extended-timestamp (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

logging print file (0|1|basename) [last]

Command

```
logging print file (0|1|basename) [last]
```

Parameters

logging

Configure logging

print

Log output settings

file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

basename

Prefix each log message with the source file's basename (strip leading paths) and line

[last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

logging print level (0|1)

Command

```
logging print level (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

logging set-log-mask MASK

Command

```
logging set-log-mask MASK
```

Parameters

logging

Configure logging

set-log-mask

Set the logmask of this logging target

MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL_DEBUG=1 LOGL_INFO=3 LOGL_NOTICE=5 LOGL_ERROR=7 LOGL_FATAL=8

logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging

Configure logging

timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

logp ([gprs|ns|bssgp|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgs...

Command

```
logp ([gprs|ns|bssgp|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup|loap ↵
|lss7|lscpp|lsua|lm3ua|lmgcp|ljibuf|lrspro) (debug|info|notice|error|fatal) . ↵
LOGMESSAGE
```

Parameters

logp

Print a message on all log outputs; useful for placing markers in test logs

gprs
GPRS Packet Service

ns
GPRS Network Service (NS)

bssgp
GPRS BSS Gateway Protocol (BSSGP)

lglobal
Library-internal global log family

llapd
LAPD in libosmogsm

linp
A-bis Input Subsystem

lmux
A-bis B-Subchannel TRAU Frame Multiplex

lmi
A-bis Input Driver for Signalling

lmib
A-bis Input Driver for B-Channels (voice)

lsms
Layer3 Short Message Service (SMS)

lctrl
Control Interface

lgtp
GPRS GTP library

lstats
Statistics messages and logging

lgsup
Generic Subscriber Update Protocol

loap
Osmocom Authentication Protocol

lss7
libosmo-sigtran Signalling System 7

lsccp
libosmo-sigtran SCCP Implementation

lsua
libosmo-sigtran SCCP User Adaptation

lm3ua
libosmo-sigtran MTP3 User Adaptation

lmgcp

libosmo-mgcp Media Gateway Control Protocol

ljibuf

libosmo-netif Jitter Buffer

lrspro

Remote SIM protocol

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

.LOGMESSAGE

Arbitrary message to log on given category and log level

no logging level force-all**Command**

```
no logging level force-all
```

Parameters**no**

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

show alarms

Command

```
show alarms
```

Parameters

show

Show running system information

alarms

Show current logging configuration

show asciidoc counters

Command

```
show asciidoc counters
```

Parameters

show

Show running system information

asciidoc

Asciidoc generation

counters

Generate table of all registered counters

show gbproxy [stats]

Command

```
show gbproxy [stats]
```

Parameters

show

Show running system information

gbproxy

Display information about the Gb proxy

[stats]

Show statistics

show gbproxy links

Command

```
show gbproxy links
```

Parameters

show

Show running system information

gbproxy

Display information about the Gb proxy

links

Show logical links

show history

Command

```
show history
```

Parameters

show

Show running system information

history

Display the session command history

show logging vty

Command

```
show logging vty
```

Parameters

show

Show running system information

logging

Show current logging configuration

vty

Show current logging configuration for this vty

show ns

Command

```
show ns
```

Parameters

show

Show running system information

ns

Display information about the NS protocol

show ns (nsei|nsvc) <0-65535> [stats]

Command

```
show ns (nsei|nsvc) <0-65535> [stats]
```

Parameters

show

Show running system information

ns

Display information about the NS protocol

nsei

Select one NSE by its NSE Identifier

nsvc

Select one NSE by its NS-VC Identifier

<0-65535>

The Identifier of selected type

[stats]

Include Statistics

show ns persistent

Command

```
show ns persistent
```

Parameters

show

Show running system information

ns

Display information about the NS protocol

persistent

Show only persistent NS

show ns stats

Command

```
show ns stats
```

Parameters

show

Show running system information

ns

Display information about the NS protocol

stats

Include statistics

show online-help

Command

```
show online-help
```

Parameters

show

Show running system information

online-help

Online help

show rate-counters

Command

```
show rate-counters
```

Parameters

show

Show running system information

rate-counters

Show all rate counters

show stats

Command

```
show stats
```

Parameters

show

Show running system information

stats

Show statistical values

show stats level (global|peer|subscriber)

Command

```
show stats level (global|peer|subscriber)
```

Parameters

show

Show running system information

stats

Show statistical values

level

Set the maximum group level

global

Show global groups only

peer

Show global and network peer related groups

subscriber

Show global, peer, and subscriber groups

show talloc-context (application|all) (full|brief|DEPTH)

Command

```
show talloc-context (application|all) (full|brief|DEPTH)
```

Parameters

show

Show running system information

talloc-context
Show talloc memory hierarchy

application
Application's context

all
All contexts, if NULL-context tracking is enabled

full
Display a full talloc memory hierarchy

brief
Display a brief talloc memory hierarchy

DEPTH
Specify required maximal depth value

show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP

Command

```
show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP
```

Parameters

show
Show running system information

talloc-context
Show talloc memory hierarchy

application
Application's context

all
All contexts, if NULL-context tracking is enabled

full
Display a full talloc memory hierarchy

brief
Display a brief talloc memory hierarchy

DEPTH
Specify required maximal depth value

filter
Filter chunks using regular expression

REGEXP
Regular expression

show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS

Command

```
show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS
```

Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

tree

Display only a specific memory chunk

ADDRESS

Chunk address (e.g. 0xdeadbeef)

show version

Command

```
show version
```

Parameters

show

Show running system information

version

Displays program version

terminal length <0-512>

Command

```
terminal length <0-512>
```

Parameters

terminal

Set terminal line parameters

length

Set number of lines on a screen

<0-512>

Number of lines on screen (0 for no pausing)

terminal no length

Command

```
terminal no length
```

Parameters

terminal

Set terminal line parameters

no

Negate a command or set its defaults

length

Set number of lines on a screen

who

Command

```
who
```

Parameters

who

Display who is on vty

enable

The enable node is a privileged node, allowing to make changes to the configuration and to access further commands like 'configure'. All commands seen on the view node are also available here.

configure terminal

Command

```
configure terminal
```

Parameters

configure

Configuration from vty interface

terminal

Configuration terminal

copy running-config startup-config

Command

```
copy running-config startup-config
```

Parameters

copy

Copy configuration

running-config

Copy running config to...

startup-config

Copy running config to startup config (same as write file)

delete-gbproxy-link <0-65534> (stale|de-registered)

Command

```
delete-gbproxy-link <0-65534> (stale|de-registered)
```

Parameters

delete-gbproxy-link

Delete a GBProxy logical link entry by NSEI and identification

<0-65534>

NSEI number

stale

Delete stale entries

de-registered

Delete de-registered entries

delete-gbproxy-link <0-65534> (tlli|imsi|sgsn-nsei) IDENT

Command

```
delete-gbproxy-link <0-65534> (tlli|imsi|sgsn-nsei) IDENT
```

Parameters

delete-gbproxy-link

Delete a GBProxy logical link entry by NSEI and identification

<0-65534>

NSEI number

tlli

Delete entries with a matching TLLI (hex)

imsi

Delete entries with a matching IMSI

sgsn-nsei

Delete entries with a matching SGSN NSEI

IDENT

Identification to match

delete-gbproxy-peer <0-65534> (only-bvc|only-nsvc|all) [dry-run]

Command

```
delete-gbproxy-peer <0-65534> (only-bvc|only-nsvc|all) [dry-run]
```

Parameters

delete-gbproxy-peer

Delete a GBProxy peer by NSEI and optionally BVCI

<0-65534>

NSEI number

only-bvc

Only delete BSSGP connections (BVC)

only-nsvc

Only delete dynamic NS connections (NS-VC)

all

Delete BVC and dynamic NS connections

[dry-run]

Show what would be deleted instead of actually deleting

delete-gbproxy-peer <0-65534> bvci <2-65534>

Command

```
delete-gbproxy-peer <0-65534> bvci <2-65534>
```

Parameters

delete-gbproxy-peer

Delete a GBProxy peer by NSEI and optionally BVCI

<0-65534>

NSEI number

bvci

Only delete peer with a matching BVCI

<2-65534>

BVCI number

disable

Command

```
disable
```

Parameters

disable

Turn off privileged mode command

logging color (0|1)

Command

```
logging color (0|1)
```

Parameters

logging

Configure logging

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

logging disable

Command

```
logging disable
```

Parameters

logging

Configure logging

disable

Disables logging to this vty

logging enable

This command is required to make logging commands available on the telnet VTY.

Command

```
logging enable
```

Parameters

logging

Configure logging

enable

Enables logging to this vty

logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

Command

```
logging filter all (0|1)
```

Parameters

logging

Configure logging

filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

logging filter nsvc (nsei|nsvci) <0-65535>

Command

```
logging filter nsvc (nsei|nsvci) <0-65535>
```

Parameters

logging

Configure logging

filter

Filter log messages

nsvc

Filter based on NS Virtual Connection

nsei

Identify NS-VC by NSEI

nsvci

Identify NS-VC by NSVCI

<0-65535>

Numeric identifier

logging level (|gprs|ns|bssgp|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|l...

Command

```
logging level (|gprs|ns|bssgp|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats| ↵  
lgsup|loap|lss7|lsccp|lsua|lm3ua|lmgcp|ljibuf|lrspro) (debug|info|notice|error| ↵  
fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

gprs

GPRS Packet Service

ns

GPRS Network Service (NS)

bssgp

GPRS BSS Gateway Protocol (BSSGP)

lglobal

Library-internal global log family

llapd
LAPD in libosmogsm

linp
A-bis Input Subsystem

lmux
A-bis B-Subchannel TRAU Frame Multiplex

lmi
A-bis Input Driver for Signalling

lmib
A-bis Input Driver for B-Channels (voice)

lsms
Layer3 Short Message Service (SMS)

lctrl
Control Interface

lgtp
GPRS GTP library

lstats
Statistics messages and logging

lgsup
Generic Subscriber Update Protocol

loap
Osmocom Authentication Protocol

lss7
libosmo-sigtran Signalling System 7

lsccp
libosmo-sigtran SCCP Implementation

lsua
libosmo-sigtran SCCP User Adaptation

lm3ua
libosmo-sigtran MTP3 User Adaptation

lmgcp
libosmo-mgcp Media Gateway Control Protocol

ljibuf
libosmo-netif Jitter Buffer

lrspro
Remote SIM protocol

debug
Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

logging level force-all (debug|info|notice|error|fatal)**Command**

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters**logging**

Configure logging

level

Set the log level for a specified category

force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

logging level set-all (debug|info|notice|error|fatal)**Command**

```
logging level set-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

logging print extended-timestamp (0|1)

Command

```
logging print extended-timestamp (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

logging print file (0|1|basename) [last]

Command

```
logging print file (0|1|basename) [last]
```

Parameters

logging

Configure logging

print

Log output settings

file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

basename

Prefix each log message with the source file's basename (strip leading paths) and line

[last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

logging print level (0|1)

Command

```
logging print level (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

logging set-log-mask MASK

Command

```
logging set-log-mask MASK
```

Parameters

logging

Configure logging

set-log-mask

Set the logmask of this logging target

MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL_DEBUG=1 LOGL_INFO=3 LOGL_NOTICE=5 LOGL_ERROR=7 LOGL_FATAL=8

logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging

Configure logging

timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

logp ([gprs|ns|bssgp|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgs...

Command

```
logp ([gprs|ns|bssgp|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup|loap ↵
|lss7|lscpp|lsua|lm3ua|lmgcp|ljibuf|lrspro) (debug|info|notice|error|fatal) . ↵
LOGMESSAGE
```

Parameters

logp

Print a message on all log outputs; useful for placing markers in test logs

gprs
GPRS Packet Service

ns
GPRS Network Service (NS)

bssgp
GPRS BSS Gateway Protocol (BSSGP)

lglobal
Library-internal global log family

llapd
LAPD in libosmogsm

linp
A-bis Input Subsystem

lmux
A-bis B-Subchannel TRAU Frame Multiplex

lmi
A-bis Input Driver for Signalling

lmib
A-bis Input Driver for B-Channels (voice)

lsms
Layer3 Short Message Service (SMS)

lctrl
Control Interface

lgtp
GPRS GTP library

lstats
Statistics messages and logging

lgsup
Generic Subscriber Update Protocol

loap
Osmocom Authentication Protocol

lss7
libosmo-sigtran Signalling System 7

lsccp
libosmo-sigtran SCCP Implementation

lsua
libosmo-sigtran SCCP User Adaptation

lm3ua
libosmo-sigtran MTP3 User Adaptation

lmgcp
libosmo-mgcp Media Gateway Control Protocol

ljibuf
libosmo-netif Jitter Buffer

lrspro
Remote SIM protocol

debug
Log debug messages and higher levels

info
Log informational messages and higher levels

notice
Log noticeable messages and higher levels

error
Log error messages and higher levels

fatal
Log only fatal messages

.LOGMESSAGE
Arbitrary message to log on given category and log level

no logging level force-all

Command

```
no logging level force-all
```

Parameters

no
Negate a command or set its defaults

logging
Configure logging

level
Set the log level for a specified category

force-all
Release any globally forced log level set with 'logging level force-all <level>'

nsvc (nsei|nsvci) <0-65535> (block|unblock|reset)

Command

```
nsvc (nsei|nsvci) <0-65535> (block|unblock|reset)
```

Parameters

nsvc

Perform an operation on a NSVC

nsei

NSEI to identify NS-VC Identifier (NS-VCI)

nsvci

NS-VC Identifier (NS-VCI)

<0-65535>

The NSEI

block

Initiate BLOCK procedure

unblock

Initiate UNBLOCK procedure

reset

Initiate RESET procedure

show alarms

Command

```
show alarms
```

Parameters

show

Show running system information

alarms

Show current logging configuration

show asciidoc counters

Command

```
show asciidoc counters
```

Parameters

show

Show running system information

asciidoc

Asciidoc generation

counters

Generate table of all registered counters

show gbproxy [stats]

Command

```
show gbproxy [stats]
```

Parameters

show

Show running system information

gbproxy

Display information about the Gb proxy

[stats]

Show statistics

show gbproxy links

Command

```
show gbproxy links
```

Parameters

show

Show running system information

gbproxy

Display information about the Gb proxy

links

Show logical links

show history

Command

```
show history
```

Parameters

show

Show running system information

history

Display the session command history

show logging vty

Command

```
show logging vty
```

Parameters

show

Show running system information

logging

Show current logging configuration

vtv

Show current logging configuration for this vty

show ns

Command

```
show ns
```

Parameters

show

Show running system information

ns

Display information about the NS protocol

show ns (nsei|nsvc) <0-65535> [stats]

Command

```
show ns (nsei|nsvc) <0-65535> [stats]
```

Parameters

show

Show running system information

ns

Display information about the NS protocol

nsei

Select one NSE by its NSE Identifier

nsvc

Select one NSE by its NS-VC Identifier

<0-65535>

The Identifier of selected type

[stats]

Include Statistics

show ns persistent

Command

```
show ns persistent
```

Parameters

show

Show running system information

ns

Display information about the NS protocol

persistent

Show only persistent NS

show ns stats

Command

```
show ns stats
```

Parameters

show

Show running system information

ns

Display information about the NS protocol

stats

Include statistics

show online-help

Command

```
show online-help
```

Parameters

show

Show running system information

online-help

Online help

show rate-counters

Command

```
show rate-counters
```

Parameters

show

Show running system information

rate-counters

Show all rate counters

show startup-config

Command

```
show startup-config
```

Parameters

show

Show running system information

startup-config

Contentes of startup configuration

show stats

Command

```
show stats
```

Parameters

show

Show running system information

stats

Show statistical values

show stats level (global|peer|subscriber)

Command

```
show stats level (global|peer|subscriber)
```

Parameters

show

Show running system information

stats

Show statistical values

level

Set the maximum group level

global

Show global groups only

peer

Show global and network peer related groups

subscriber

Show global, peer, and subscriber groups

show talloc-context (application|all) (full|brief|DEPTH)

Command

```
show talloc-context (application|all) (full|brief|DEPTH)
```

Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP

Command

```
show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP
```

Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

filter

Filter chunks using regular expression

REGEXP

Regular expression

show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS

Command

```
show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS
```

Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

tree

Display only a specific memory chunk

ADDRESS

Chunk address (e.g. 0xdeadbeef)

show version

Command

```
show version
```

Parameters

show

Show running system information

version

Displays program version

terminal length <0-512>

Command

```
terminal length <0-512>
```

Parameters

terminal

Set terminal line parameters

length

Set number of lines on a screen

<0-512>

Number of lines on screen (0 for no pausing)

terminal monitor

Command

```
terminal monitor
```

Parameters

terminal

Set terminal line parameters

monitor

Copy debug output to the current terminal line

terminal no length

Command

```
terminal no length
```

Parameters

terminal

Set terminal line parameters

no

Negate a command or set its defaults

length

Set number of lines on a screen

terminal no monitor

Command

```
terminal no monitor
```

Parameters

terminal

Set terminal line parameters

no

Negate a command or set its defaults

monitor

Copy debug output to the current terminal line

who

Command

```
who
```

Parameters

who

Display who is on vty

config

The config node is the root for all configuration commands, which are identical to the config file format. Changes made on the telnet VTY can be made persistent with the 'write file' command.

banner motd default

Command

```
banner motd default
```

Parameters

banner

Set banner string

motd

Strings for motd

default

Default string

banner motd file [FILE]

Command

```
banner motd file [FILE]
```

Parameters

banner

Set banner

motd

Banner for motd

file

Banner from a file

[FILE]

Filename

enable password (8|) WORD

Command

```
enable password (8|) WORD
```

Parameters

enable

Modify enable password parameters

password

Assign the privileged level password

8

Specifies a HIDDEN password will follow

dummy string

WORD

The HIDDEN 'enable' password string

enable password LINE

Command

```
enable password LINE
```

Parameters

enable

Modify enable password parameters

password

Assign the privileged level password

LINE

The UNENCRYPTED (cleartext) 'enable' password

gbproxy

Command

```
gbproxy
```

Parameters

gbproxy

Configure the Gb proxy

hostname WORD

Command

```
hostname WORD
```

Parameters

hostname

Set system's network name

WORD

This system's network name

line vty

Command

```
line vty
```

Parameters

line

Configure a terminal line

vtty

Virtual terminal

log alarms <2-32700>

Command

```
log alarms <2-32700>
```

Parameters

log

Configure logging sub-system

alarms

Logging alarms to osmo_strrb

<2-32700>

Maximum number of messages to log

log file .FILENAME

Command

```
log file .FILENAME
```

Parameters

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

log gsmtap [HOSTNAME]

Command

```
log gsmtap [HOSTNAME]
```

Parameters

log

Configure logging sub-system

gsmtap

Logging via GSMTAP

[HOSTNAME]

Host name to send the GSMTAP logging to (UDP port 4729)

log stderr

Command

```
log stderr
```

Parameters

log

Configure logging sub-system

stderr

Logging via STDERR of the process

log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)

Command

```
log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)
```

Parameters

log

Configure logging sub-system

syslog

Logging via syslog

authpriv

Security/authorization messages facility

cron

Clock daemon (cron/at) facility

daemon

General system daemon facility

ftp

Ftp daemon facility

lpr

Line printer facility

mail

Mail facility

news

News facility

user

Generic facility

uucp

UUCP facility

log syslog local <0-7>

Command

```
log syslog local <0-7>
```

Parameters

log

Configure logging sub-system

syslog

Logging via syslog

local

Syslog LOCAL facility

<0-7>

Local facility number

no banner motd

Command

```
no banner motd
```

Parameters

no

Negate a command or set its defaults

banner

Set banner string

motd

Strings for motd

no enable password

Command

```
no enable password
```

Parameters

no

Negate a command or set its defaults

enable

Modify enable password parameters

password

Assign the privileged level password

no hostname [HOSTNAME]

Command

```
no hostname [HOSTNAME]
```

Parameters

no

Negate a command or set its defaults

hostname

Reset system's network name

[HOSTNAME]

Host name of this router

no log alarms

Command

```
no log alarms
```

Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

alarms

Logging alarms to osmo_strrb

no log file .FILENAME

Command

```
no log file .FILENAME
```

Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

no log stderr

Command

```
no log stderr
```

Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

stderr

Logging via STDERR of the process

no log syslog

Command

```
no log syslog
```

Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

syslog

Logging via syslog

no service advanced-vty

Command

```
no service advanced-vty
```

Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

no service terminal-length [<0-512>]

Command

```
no service terminal-length [<0-512>]
```

Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

[<0-512>]

Number of lines of VTY (0 means no line control)

no stats reporter log

Command

```
no stats reporter log
```

Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

no stats reporter statsd

Command

```
no stats reporter statsd
```

Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

ns

Command

```
ns
```

Parameters

ns

Configure the GPRS Network Service

password (8|) WORD

Command

```
password (8|) WORD
```

Parameters

password

Assign the terminal connection password

8

Specifies a HIDDEN password will follow

dummy string

WORD

The HIDDEN line password string

password LINE

Command

```
password LINE
```

Parameters

password

Assign the terminal connection password

LINE

The UNENCRYPTED (cleartext) line password

service advanced-vty

Command

```
service advanced-vty
```

Parameters

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

service terminal-length <0-512>

Command

```
service terminal-length <0-512>
```

Parameters

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

<0-512>

Number of lines of VTY (0 means no line control)

show history

Command

```
show history
```

Parameters

show

Show running system information

history

Display the session command history

stats interval <1-65535>

Command

```
stats interval <1-65535>
```

Parameters

stats

Configure stats sub-system

interval

Set the reporting interval

<1-65535>

Interval in seconds

stats reporter log

Command

```
stats reporter log
```

Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

stats reporter statsd

Command

```
stats reporter statsd
```

Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

config-log

The log node is commonly available in all Osmocom programs and allows configuring logging to stderr and/or log files, including logging category and level filtering as well as output formatting options. Note that the 'logging enable' command is required to make logging commands available on the telnet VTY.

logging color (0|1)

Command

```
logging color (0|1)
```

Parameters

logging

Configure logging

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

Command

```
logging filter all (0|1)
```

Parameters

logging

Configure logging

filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

logging filter nsvc (nsei|nsvci) <0-65535>

Command

```
logging filter nsvc (nsei|nsvci) <0-65535>
```

Parameters

logging

Configure logging

filter

Filter log messages

nsvc

Filter based on NS Virtual Connection

nsei

Identify NS-VC by NSEI

nsvci

Identify NS-VC by NSVCI

<0-65535>

Numeric identifier

logging level (|gprs|ns|bssgp|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|l...

Command

```
logging level (|gprs|ns|bssgp|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|↵  
lgsup|loap|lss7|lscdp|lsua|lm3ua|lmgcp|ljibuf|lrspro) (debug|info|notice|error|↵  
fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

gprs

GPRS Packet Service

ns

GPRS Network Service (NS)

bssgp

GPRS BSS Gateway Protocol (BSSGP)

lglobal

Library-internal global log family

llapd

LAPD in libosmogsm

linp

A-bis Input Subsystem

lmux

A-bis B-Subchannel TRAU Frame Multiplex

lmi

A-bis Input Driver for Signalling

lmib
A-bis Input Driver for B-Channels (voice)

lsms
Layer3 Short Message Service (SMS)

lctrl
Control Interface

lgtp
GPRS GTP library

lstats
Statistics messages and logging

lgsup
Generic Subscriber Update Protocol

loap
Osmocom Authentication Protocol

lss7
libosmo-sigtran Signalling System 7

lsccp
libosmo-sigtran SCCP Implementation

lsua
libosmo-sigtran SCCP User Adaptation

lm3ua
libosmo-sigtran MTP3 User Adaptation

lmgcp
libosmo-mgcp Media Gateway Control Protocol

ljibuf
libosmo-netif Jitter Buffer

lrspro
Remote SIM protocol

debug
Log debug messages and higher levels

info
Log informational messages and higher levels

notice
Log noticeable messages and higher levels

error
Log error messages and higher levels

fatal
Log only fatal messages

logging level force-all (debug|info|notice|error|fatal)

Command

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

logging level set-all (debug|info|notice|error|fatal)

Command

```
logging level set-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

logging print extended-timestamp (0|1)

Command

```
logging print extended-timestamp (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

logging print file (0|1|basename) [last]

Command

```
logging print file (0|1|basename) [last]
```

Parameters

logging

Configure logging

print

Log output settings

file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

basename

Prefix each log message with the source file's basename (strip leading paths) and line

[last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

logging print level (0|1)

Command

```
logging print level (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging

Configure logging

timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

no logging level force-all

Command

```
no logging level force-all
```

Parameters

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

config-stats

disable

Command

```
disable
```

Parameters

disable

Disable the reporter

enable

Command

```
enable
```

Parameters

enable

Enable the reporter

level (global|peer|subscriber)

Command

```
level (global|peer|subscriber)
```

Parameters

level

Set the maximum group level

global

Report global groups only

peer

Report global and network peer related groups

subscriber

Report global, peer, and subscriber groups

local-ip ADDR

Command

```
local-ip ADDR
```

Parameters

local-ip

Set the IP address to which we bind locally

ADDR

IP Address

mtu <100-65535>

Command

```
mtu <100-65535>
```

Parameters

mtu

Set the maximum packet size

<100-65535>

Size in byte

no local-ip

Command

```
no local-ip
```

Parameters

no

Negate a command or set its defaults

local-ip

Set the IP address to which we bind locally

no mtu

Command

```
no mtu
```

Parameters

no

Negate a command or set its defaults

mtu

Set the maximum packet size

no prefix

Command

```
no prefix
```

Parameters

no

Negate a command or set its defaults

prefix

Set the item name prefix

prefix PREFIX

Command

```
prefix PREFIX
```

Parameters

prefix

Set the item name prefix

PREFIX

The prefix string

remote-ip ADDR

Command

```
remote-ip ADDR
```

Parameters

remote-ip

Set the remote IP address to which we connect

ADDR

IP Address

remote-port <1-65535>

Command

```
remote-port <1-65535>
```

Parameters

remote-port

Set the remote port to which we connect

<1-65535>

Remote port number

config-line

bind A.B.C.D [<0-65535>]

Command

```
bind A.B.C.D [<0-65535>]
```

Parameters

bind

Accept VTY telnet connections on local interface

A.B.C.D

Local interface IP address (default: 127.0.0.1)

[<0-65535>]

Local TCP port number

login

Command

```
login
```

Parameters

login

Enable password checking

no login

Command

```
no login
```

Parameters

no

Negate a command or set its defaults

login

Enable password checking

config-ns

encapsulation framerelay-gre enabled (1|0)

Command

```
encapsulation framerelay-gre enabled (1|0)
```

Parameters

encapsulation

NS encapsulation options

framerelay-gre

NS over Frame Relay over GRE Encapsulation

enabled

Enable or disable Frame Relay over GRE

1

Enable

0

Disable

encapsulation framerelay-gre local-ip A.B.C.D

Command

```
encapsulation framerelay-gre local-ip A.B.C.D
```

Parameters

encapsulation

NS encapsulation options

framerelay-gre

NS over Frame Relay over GRE Encapsulation

local-ip

Set the IP address on which we listen for NS/FR/GRE

A.B.C.D

IP Address

encapsulation udp dscp <0-255>

Command

```
encapsulation udp dscp <0-255>
```

Parameters

encapsulation

NS encapsulation options

udp

NS over UDP Encapsulation

dscp

Set DSCP/TOS on the UDP socket

<0-255>

DSCP Value

encapsulation udp local-ip A.B.C.D

Command

```
encapsulation udp local-ip A.B.C.D
```

Parameters

encapsulation

NS encapsulation options

udp

NS over UDP Encapsulation

local-ip

Set the IP address on which we listen for NS/UDP

A.B.C.D

IP Address

encapsulation udp local-port <0-65535>

Command

```
encapsulation udp local-port <0-65535>
```

Parameters

encapsulation

NS encapsulation options

udp

NS over UDP Encapsulation

local-port

Set the UDP port on which we listen for NS/UDP

<0-65535>

UDP port number

no nse <0-65535>

Command

```
no nse <0-65535>
```

Parameters

no

Delete Persistent NS Entity

nse

Delete Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

nse <0-65535> encapsulation (udp|framerelay-gre)

Command

```
nse <0-65535> encapsulation (udp|framerelay-gre)
```

Parameters

nse

Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

encapsulation

Encapsulation for NS

udp

UDP/IP Encapsulation

framerelay-gre

Frame-Relay/GRE/IP Encapsulation

nse <0-65535> fr-dlci <16-1007>

Command

```
nse <0-65535> fr-dlci <16-1007>
```

Parameters

nse

Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

fr-dlci

Frame Relay DLCI

<16-1007>

Frame Relay DLCI Number

nse <0-65535> nsvci <0-65534>

Command

```
nse <0-65535> nsvci <0-65534>
```

Parameters

nse

Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

nsvci

NS Virtual Connection

<0-65534>

NS Virtual Connection ID (NSVCI)

nse <0-65535> remote-ip A.B.C.D

Command

```
nse <0-65535> remote-ip A.B.C.D
```

Parameters

nse

Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

remote-ip

Remote IP Address

A.B.C.D

Remote IP Address

nse <0-65535> remote-port <0-65535>

Command

```
nse <0-65535> remote-port <0-65535>
```

Parameters

nse

Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

remote-port

Remote UDP Port

<0-65535>

Remote UDP Port Number

nse <0-65535> remote-role (sgsn|bss)

Command

```
nse <0-65535> remote-role (sgsn|bss)
```

Parameters

nse

Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

remote-role

Remote NSE Role

sgsn

Remote Peer is SGSN

bss

Remote Peer is BSS

timer (tns-block|tns-block-retries|tns-reset|tns-reset-retries|tns-test|tns-aliv...

Command

```
timer (tns-block|tns-block-retries|tns-reset|tns-reset-retries|tns-test|tns-alive|tns- ↵  
    alive-retries|tsns-prov) <0-65535>
```

Parameters

timer

Network Service Timer

tns-block

(un)blocking Timer (Tns-block) timeout

tns-block-retries

(un)blocking Timer (Tns-block) number of retries

tns-reset

Reset Timer (Tns-reset) timeout

tns-reset-retries

Reset Timer (Tns-reset) number of retries

tns-test

Test Timer (Tns-test) timeout

tns-alive

Alive Timer (Tns-alive) timeout

tns-alive-retries

Alive Timer (Tns-alive) number of retries

tsns-prov

SNS Provision Timer (Tsns-prov) timeout

<0-65535>

Timer Value

config-gbproxy

Configure the Gb proxy

acquire-imsi

Command

```
acquire-imsi
```

Parameters

acquire-imsi

Acquire the IMSI before establishing a LLC connection (Experimental)

core-access-point-name (APN|none)

Command

```
core-access-point-name (APN|none)
```

Parameters

core-access-point-name

Use this access point name (APN) for the backbone

APN

Replace APN by this string

none

Remove APN

core-mobile-country-code <1-999>

Command

```
core-mobile-country-code <1-999>
```

Parameters

core-mobile-country-code

Use this country code for the core network

<1-999>

MCC value

core-mobile-network-code <1-999>

Command

```
core-mobile-network-code <1-999>
```

Parameters

core-mobile-network-code

Use this network code for the core network

<1-999>

NCC value

link stored-msgs-max-length <1-99999>

Command

```
link stored-msgs-max-length <1-99999>
```

Parameters

link

Set TLLI parameters

stored-msgs-max-length

Limit list length

<1-99999>

Maximum number of msgb stored in the logical link waiting to acquire its IMSI

link-list clean-stale-timer <1-999999>

Command

```
link-list clean-stale-timer <1-999999>
```

Parameters

link-list

Set TLLI list parameters

clean-stale-timer

Periodic timer to clean stale links

<1-999999>

Frequency at which the periodic timer is fired (in seconds)

link-list keep-mode (never|re-attach|identified|always)

Command

```
link-list keep-mode (never|re-attach|identified|always)
```

Parameters

link-list

Set TLLI list parameters

keep-mode

How to keep entries for detached logical links

never

Discard entry immediately after detachment

re-attach

Keep entry if a re-attachment has be requested

identified

Keep entry if it associated with an IMSI

always

Don't discard entries after detachment

link-list max-age <1-999999>

Command

```
link-list max-age <1-999999>
```

Parameters

link-list

Set TLLI list parameters

max-age

Limit maximum age

<1-999999>

Maximum age in seconds

link-list max-length <1-99999>

Command

```
link-list max-length <1-99999>
```

Parameters

link-list

Set TLLI list parameters

max-length

Limit list length

<1-99999>

Maximum number of logical links in the list

match-imsi (patching|routing) .REGEXP

Command

```
match-imsi (patching|routing) .REGEXP
```

Parameters

match-imsi

Restrict actions to certain IMSIs

patching

Patch MS related information elements on match only

routing

Route to the secondary SGSN on match only

.REGEXP

Regular expression for the IMSI match

no acquire-imsi

Command

```
no acquire-imsi
```

Parameters

no

Negate a command or set its defaults

acquire-imsi

Acquire the IMSI before establishing a LLC connection (Experimental)

no core-access-point-name

Command

```
no core-access-point-name
```

Parameters

no

Negate a command or set its defaults

core-access-point-name

Use this access point name (APN) for the backbone

no core-mobile-country-code

Command

```
no core-mobile-country-code
```

Parameters

no

Negate a command or set its defaults

core-mobile-country-code

Use this country code for the core network

no core-mobile-network-code

Command

```
no core-mobile-network-code
```

Parameters

no

Negate a command or set its defaults

core-mobile-network-code

Use this network code for the core network

no link stored-msgs-max-length

Command

```
no link stored-msgs-max-length
```

Parameters

no

Negate a command or set its defaults

link

Set TLLI parameters

stored-msgs-max-length

Limit list length

no link-list clean-stale-timer

Command

```
no link-list clean-stale-timer
```

Parameters

no

Negate a command or set its defaults

link-list

Set TLLI list parameters

clean-stale-timer

Periodic timer to clean stale links

no link-list max-age

Command

```
no link-list max-age
```

Parameters

no

Negate a command or set its defaults

link-list

Set TLLI list parameters

max-age

Limit maximum age

no link-list max-length

Command

```
no link-list max-length
```

Parameters

no

Negate a command or set its defaults

link-list

Set TLLI list parameters

max-length

Limit list length

no match-imsi

Command

```
no match-imsi
```

Parameters

no

Negate a command or set its defaults

match-imsi

Restrict actions to certain IMSIs

no patch-ptmsi

Command

```
no patch-ptmsi
```

Parameters

no

Negate a command or set its defaults

patch-ptmsi

Patch P-TMSI/TLLI

no secondary-sgsn

Command

```
no secondary-sgsn
```

Parameters

no

Negate a command or set its defaults

secondary-sgsn

Route matching LLC connections to a second SGSN (Experimental)

patch-ptmsi

Command

```
patch-ptmsi
```

Parameters

patch-ptmsi

Patch P-TMSI/TLLI

secondary-sgsn nsei <0-65534>

Command

```
secondary-sgsn nsei <0-65534>
```

Parameters

secondary-sgsn

Route matching LLC connections to a second SGSN (Experimental)

nsei

NSEI to be used in the connection with the SGSN

<0-65534>

The NSEI

sgsn nsei <0-65534>

Command

```
sgsn nsei <0-65534>
```

Parameters

sgsn

SGSN information

nsei

NSEI to be used in the connection with the SGSN

<0-65534>

The NSEI